

Copyright 2004-2005 Kate Cygnar/SavvySeams. Some rights reserved.

Visit <http://www.savvyseams.com/> or email info@savvyseams.com for more information.

This work is licensed under the Creative Commons Attribution-NonCommercial-ShareAlike License.

To view a copy of this license, visit <http://creativecommons.org/licenses/by-nc-sa/2.0/>
or send a letter to Creative Commons, 559 Nathan Abbott Way, Stanford, California 94305, USA.

General Information About This Pattern

It is very important that you print this pattern out WITHOUT SCALING or RESIZING.

These options are in the print dialog box (the window that pops up when you go to print).

**To confirm the pattern is printed correctly,
measure either the large grid (should 8x10 inches)
or the small grid (should be 4x4 cm).**

After you print, using either a fabric pen, a fine-tip permanent marker or even a ball-point pen,
trace the patterns onto gridded pattern tracing paper or just plain, non-fusible interfacing.

See <http://www.savvyseams.com/gettingstarted.php> for more help.

Since the instructions are accompanied by photos rather than illustrations, these are available as a webpage.
If you wish to print out the instructions minus the photos, there is a link to a text file on each instructions page.

All patterns and instructions are available at

<http://www.savvyseams.com/>

1 cm

1 inch

top, bottom, back
cut 1 of fabric
cut 1 of lining

front and sides
above zipper
cut 1 of fabric
cut 1 of lining


front and sides below zipper
cut 1 of fabric
cut 1 of lining

Case for Handheld Game Player

1 cm

pattern for mesh insert

dots indicate the four corners of the top square



slash for zipper opening